



FEBLEASE1000V2ISO-01

OB-EASE1000V2-ISO

User's Manual

Issue Date: August 26, 2024

Notice

Precaution on using ROHM Products

- 1) When using ROHM Products, refer to the latest product information and ensure that usage conditions (absolute maximum ratings^{*1}, recommended operating conditions, etc.) are within the ranges specified. ROHM disclaims any and all liability for any malfunctions, failure or accident arising out of or in connection with the use of ROHM Products outside of such usage conditions specified ranges, or without observing precautions. Even if it is used within such usage conditions specified ranges, semiconductors can break down and malfunction due to various factors. Therefore, in order to prevent personal injury, fire or the other damage from break down or malfunction of ROHM Products, please take safety at your own risk measures such as complying with the derating characteristics, implementing redundant and fire prevention designs, and utilizing backups and fail-safe procedures.

^{*1}: Absolute maximum ratings: a limit value that must not be exceeded even momentarily.

- 2) The Products specified in this document are not designed to be radiation tolerant.
- 3) Descriptions of circuits, software and other related information in this document are provided only to illustrate the standard operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. And the peripheral conditions must be taken into account when designing circuits for mass production. ROHM disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, and other related information.
- 4) No license, expressly or implied, is granted hereby under any intellectual property rights or other rights of ROHM or any third party with respect to ROHM Products or the information contained in this document (including but not limited to, the Product data, drawings, charts, programs, algorithms, and application examples, etc.). Therefore, ROHM shall have no responsibility whatsoever for any dispute, concerning such rights owned by third parties, arising out of the use of such technical information.
- 5) ROHM intends our Products to be used in a way indicated in this document. Please be sure to contact a ROHM sales office if you consider the use of our Products in different way from original use indicated in this document. For use of our Products in medical systems, please be sure to contact a ROHM representative and must obtain written agreement. Do not use our Products in applications which may directly cause injuries to human life, and which require extremely high reliability, such as aerospace equipment, nuclear power control systems, and submarine repeaters, etc. ROHM disclaims any and all liability for any losses and damages incurred by you or third parties arising by using the Product for purposes not intended by us without our prior written consent.
- 6) Please use the Products in accordance with any applicable environmental laws and regulations, such as the RoHS Directive. ROHM shall have no responsibility for any damages or losses resulting non-compliance with any applicable laws or regulations.
- 7) When providing our Products and technologies contained in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, including without limitation the US Export Administration Regulations and the Foreign Exchange and Foreign Trade Act.
- 8) Please contact a ROHM sales office if you have any questions regarding the information contained in this document or ROHM's Products.
- 9) This document, in part or in whole, may not be reprinted or reproduced without prior consent of ROHM.

(Note) "ROHM" as used in this document means ROHM Co., Ltd.

Other Precaution

- 1) All information contained in this document is subject to change for the purpose of improvement, etc. without any prior notice. Before purchasing or using ROHM Products, please confirm the latest information with a ROHM sales office.
- 2) ROHM has used reasonable care to ensure the accuracy of the information contained in this document, however, ROHM shall have no responsibility for any damages, expenses or losses arising from inaccuracy or errors of such information.

LTSZ08023•01•003

Preface

This manual describes about the Isolator for EASE1000 V2 : OB-EASE1000V2-ISO.

Refer to following documents when necessary.

- LEXIDE-Ω User's Manual
- EASE1000 V2 User's Manual

Table of Contents

1. Overview.....	1
2. Component	1
3. Specification	1
4. Usage Description	2
4.1. Connecting to the target system and EASE1000 V2	2
4.2. Power supply selection on the target system	2
4.3. Power-on procedure.....	2
4.3.1. When supplying power to the target system from the DC/DC converter mounted in OB-EASE1000V2-ISO (Choose the C-5V side for the J1 jumper socket).....	2
4.3.2. When supplying power to the target system from the target system (Select the C-USR side for the J1 jumper socket)	2
4.4. Power-off Procedure	3
4.4.1. When supplying power to the target system from the DC/DC converter mounted on OB-EASE1000V2-ISO (Choose the C-5V side for the J3 jumper socket).....	3
4.4.2. When supplying power to the target system from the target system (Select the C-USR side for the J3 jumper socket)	3
5. User Interface	4
5.1. CN1	4
5.2. CNE.....	4
5.3. CN2	4
6. Supported LSI	5
7. Precaution for usage	6
8. Revision History.....	7

1. Overview

OB-EASE1000V2-ISO is an isolator for EASE1000 V2.

Use this product when the VSS potential between EASE1000 V2 and the target system does not match, or when debugging in an environment that is easily affected by power supply noise.



Figure 1 Outline Diagram

2. Component

Table 1 Component

Name	Contents	Quantity
OB-EASE1000V2-ISO	Isolator body for EASE1000 V2	1
14-pin flat cable	Cable for connecting OB-EASE1000V2-ISO to the target system.	1

3. Specification

Table 2 Specification list

EASE1000 V2 side	Specification	
Input voltage	3.3V	Uses the 3.3V supply function of EASE1000 V2.
Target system side	Specification	
Input voltage	4.5V~5.5V	Supplied from the target system.
Output voltage	5V±10%, 250mW	Generated inside OB-EASE1000V2-ISO.
Load capacity	Max. 100pF	RST_OUT/SCK terminal, SDATA terminal.
Cable length	Max. 300mm	
Overall	Specification	
Usage environment	5 to 40°C (no condensation)	

4. Usage Description

4.1. Connecting to the target system and EASE1000 V2

- (1) Make sure the power of the target system is OFF.
- (2) Make sure EASE1000 V2 is not connected to the USB cable.
- (3) Use the 14-pin flat cable included in the configuration to connect CN1 of OB-EASE1000V2-ISO to the connector of the target system. *1
- (4) Use the 14-pin flat cable of EASE1000 V2 to connect CN2 of OB-EASE1000V2-ISO to EASE1000 V2. *1

[Note]

*1 Please make sure to align pin 1 and connect securely.




Figure 2 Connecting to the target system and EASE1000 V2

4.2. Power supply selection on the target system

Select the power supply for the target system with the jumper socket J1.

Table 3 Power supply selection on the target system

Jumper Socket Settings	Contents	Specification
C-5V side	Supplied from the DC/DC converter mounted on OB-EASE1000V2-ISO.	5V \pm 10%, 250mW
C-USR side	Supply from the target system (CN1 pin 1 or CNE pin 5).	4.5V~5.5V

4.3. Power-on procedure

4.3.1. When supplying power to the target system from the DC/DC converter mounted in OB-EASE1000V2-ISO (Choose the C-5V side for the J1 jumper socket)

- (1) Connect the host PC and EASE1000 V2 with a USB cable.
- (2) Start debugging with LEXIDE-Ω on the host PC.
- (3) LED1 and LED2 will light up.

4.3.2. When supplying power to the target system from the target system (Select the C-USR side for the J1 jumper socket)

- (1) Connect the host PC and EASE1000 V2 with a USB cable.
- (2) Supply power to the target system.
- (3) LED1 will light up.
- (4) Start debugging with LEXIDE-Ω on the host PC.
- (5) LED2 will light up.

4.4. Power-off Procedure

4.4.1. When supplying power to the target system from the DC/DC converter mounted on OB-EASE1000V2-ISO

(Choose the C-5V side for the J3 jumper socket)

- (1) End debugging with LEXIDE-Ω on the host PC.
- (2) LED1 and LED2 will turn off.
- (3) Disconnect the USB cable connecting the host PC and EASE1000 V2.

4.4.2. When supplying power to the target system from the target system

(Select the C-USR side for the J3 jumper socket)

- (1) End debugging with LEXIDE-Ω on the host PC.
- (2) LED2 will turn off.
- (3) Shut down the power to the target system.
- (4) LED1 will turn off.
- (5) Disconnect the USB cable connecting the host PC and EASE1000 V2.

5. User Interface

5.1. CN1

A 14-pin connector that connects the OB-EASE1000V2-ISO and target system.

Pin No.	Name	Direction		Pin No.	Name	Direction
1	VTref	Power/Input		2	GND	power
3	VPP	N.C.*		4	GND	power
5	RST_OUT/SCK	Input/Output		6	GND	power
7	SDATA	Input/Output		8	GND	power
9	VDDL	N.C.*		10	GND	power
11	N.C.	N.C.*		12	GND	power
13	5VOUT	Power/Output		14	N.C.	N.C.*

N.C. : Not Connected

5.2. CNE

A 5-pin connector that connects the OB-EASE1000V2-ISO and target system.

Pin No.	Name	Direction
1	VTref	Power/Input
2	GND	power
3	RST_OUT/SCK	Input/Output
4	SDATA	Input/Output
5	5VOUT	Power/Output

5.3. CN2

A 14-pin connector that connects OB-EASE1000V2-ISO and EASE1000 V2.

Pin No.	Name	Direction		Pin No.	Name	Direction
1	VTref	Power/Output		2	GND	power
3	VPP	N.C.*		4	GND	power
5	RST_OUT/SCK	Input/Output		6	GND	power
7	SDATA	Input/Output		8	GND	power
9	VDDL	N.C.*		10	GND	power
11	N.C.	N.C.*		12	GND	power
13	3.3VOUT	Power/Input		14	N.C.	N.C.*

N.C. : Not Connected

6. Supported LSI

The LSIs supported by OB-EASE1000V2-ISO are as follows:

ML62Q2033/Q2035/Q2043/Q2045

7. Precaution for usage

- (1) The OB-EASE1000V2-ISO is an unfinished product and intended for research and development and for expert use in the research and development facility only. The OB-EASE1000V2-ISO is not intended to be used for volume production or parts thereof.
- (2) Since the content specified herein is subject to change for improvement without notice, confirm the latest content when using the board.
- (3) See the other documents, the LEXIDE-Ω User's Manual and the EASE1000 V2 user's manual when using the OB-EASE1000V2-ISO.
- (4) LAPIS supports replacing the board for an initial failure soon after the shipment. However LAPIS doesn't support repairing the board.
- (5) The OB-EASE1000V2-ISO have signal patterns on the underside, it might work abnormally if using on conductive materials. Use it on insulating materials or having any preventable parts.

8. Revision History

Document No.	Issue Date	Page		Description
		Previous Edition	New Edition	
FEBLEASE1000V2ISO -01	August 26, 2024	–	–	First edition.