

Power Management IC designed for "NXP® i.MX 8M"

# **BD71837AMWV Frequently Asked Questions**

#### 1. Introduction

This document question-and-answer format for BD71837AMWV which is a Power Management IC for NXP i.MX 8M System-on-Chip (SoC) platform.

#### 2. Terminologies

Term	Definition
DCR	DC Resistance
DDR	Double Data Rate
I2C	Inter-Integrated Circuit
LDO	Low Dropout
PMIC	Power Management Integrate Circuit
RTC	Real-Time Clock
SoC	System-on-Chip
UVLO	Under Voltage Lock Out
VR	Voltage Regulator

## 3. Frequently Asked Questions

#	Category	Question	Answer
1	BUCK	Could BUCK6's inductor change from 1uH to 0.47uH? Is it for efficiency?	PMIC was designed under 1uH condition for the best ripple and transient response. If the degradations in ripple and transient response are acceptable, 0.47uH can be an option.
2	I2C	What is the I2C device/slave address of PMIC?	The device address is 0x4B. Please refer to Figure4-3 of I2C Device Addressing of the datasheet.
3	Package	What is the preferred connection for 4 corner pads? To connect to ground or not?	4 corner pads are shorted to EXP-PAD internally. It is recommended to solder such corner pads to ground.
4	Product	What is the difference between BD71837MWV and BD71837AMWV?	Please refer to the technical document of "Errata information on product BD71837MWV"on the web site. BD71837MWV is no more available in mass production process.
5	I2C	Is it a problem to Pullup the SCL and SDA lines of the I2C interface to 3.3V if DVDD=1.8V?	3.3V as the pull up source is acceptable even if DVDD is 1.8V. But NVCC_I2C of the I2C domain in SoC should be 3.3V (the same voltage as the pull up source for PMIC) and DVDD in PMIC always needs to be 1.8V.able even if DVDD is 1.8V.
6	Ю	Can we apply 3.3V on power control signals: PWRON_B, PMIC_ON_REQ, PMIC_STBY_REQ, WDOG_B, RTC_RESET_B, POR_B if DVDD=1.8V?	Yes. 3.3V is acceptable for driving the control signals.
7	BUCK	Why does the discharging of BUCK7 happen later that the discharging of the others power rails?	BUCK8 needs to be de-asserted earlier than BUCK7 for the memory requirement.
8	I2C	Is there any mechanism protecting not allowed I2C access to the PMIC registers?	As the secure I2C access function, PMIC prepares the REGLOCK register which prohibits the unexpected I2C access during the operation. I2C access is locked by the register as the default setting.
10	BUCK Memory	How to I implement the different DDR memory application?	The output voltage for BUCK8 can be adjusted by U-Boot in the initial startup depending on the memory type in use. The voltage change handled by U-Boot is acceptable for PMIC because the validity in the power sequence is confirmed by NXP and no other sideband effects are found during their validation.
11	BUCK	How do I disable BUCK6 in hardware terms?	BUCK6 is initially ON as the default setting and its output voltage is monitored during the power sequence as an one of the triggers to de-assert POR_B, the power good signal to SoC. So it is not recommended to turn off BUCK6.
12	BUCK	Could BUCK6 act as a switch? Could it work in 100% duty cycle?	BUCK6 supports 100% max duty but there is the limitation for input range described as "headroom" in the datasheet. Please refer to the section in the datasheet for details.
13	Sequence	How can the start-up behavior be modified?	The way of the power state transition can be modified through the register of TRANS_COND0/1.
14	UVLO	Is it possible to modify the ULVO value?	No, it is the fixed value.

#	Category	Question	Answer
15	BUCK	According to the datasheet, BUCK7 requests only 22µF whereas all the other bucks will need 2x 22µF.	The difference comes from the lomax requirements. 1.5A for BUCK7 is lower than 3A for others.
16	BUCK	When the system doesn't need BUCK6, the inductor and output capacitors for the VR can be saved?	To avoid the emergency shutdown in PMIC, 3.3V should be externally supplied to BUCK6_FB pin. But leakage current through the discharge resistor around 33mA will flow if 3.3V is directly supplied. This leakage current can be suppressed to add the series resistor to BUCK6_FB line. The maximum value is up to 60kohm.
17	System	How to power down the system via Software?	This depends on the operating system you are using. For Linux and Android, there are shell commands like "power off" or "shutdown" which will call several routines to store content and finally power down the system. One possibility for a power-down is to de-assert the PMIC_ON_REQ line. This will cause the PMIC to power down the rails according to the sequencing requirements. Such de-assertion can be achieved while writing to the SNVS_LPCR register, bit TOP and DP_EN, according to the NXP i.MX 8M Reference Manual. For precise description of "power-down function" of the board support package including low-level driver, please contact the SoC manufacturer.

## 4. Revision History

Date	Revision Number	Description
6 <sup>th</sup> .Sep.2019	001	First Release
26 <sup>th</sup> .Nov.2019	002	The answers for #1, 2, 3, and 5 are changed.
15 <sup>th</sup> .Jan.2020	003	Added #16.
19 <sup>th</sup> , Mar. 2020	004	Added #17.

	Notes
	Notes
1)	The information contained herein is subject to change without notice.
2)	Before you use our Products, please contact our sales representative and verify the latest specifica- tions :
3)	Although ROHM is continuously working to improve product reliability and quality, semicon- ductors can break down and malfunction due to various factors. Therefore, in order to prevent personal injury or fire arising from failure, please take safety measures such as complying with the derating characteristics, implementing redundant and fire prevention designs, and utilizing backups and fail-safe procedures. ROHM shall have no responsibility for any damages arising out of the use of our Poducts beyond the rating specified by ROHM.
4)	Examples of application circuits, circuit constants and any other information contained herein are provided only to illustrate the standard usage and operations of the Products. The peripheral conditions must be taken into account when designing circuits for mass production.
5)	The technical information specified herein is intended only to show the typical functions of and examples of application circuits for the Products. ROHM does not grant you, explicitly or implicitly, any license to use or exercise intellectual property or other rights held by ROHM or any other parties. ROHM shall have no responsibility whatsoever for any dispute arising out of the use of such technical information.
6)	The Products specified in this document are not designed to be radiation tolerant.
7)	For use of our Products in applications requiring a high degree of reliability (as exemplified below), please contact and consult with a ROHM representative : transportation equipment (i.e. cars, ships, trains), primary communication equipment, traffic lights, fire/crime prevention, safety equipment, medical systems, servers, solar cells, and power transmission systems.
8)	Do not use our Products in applications requiring extremely high reliability, such as aerospace equipment, nuclear power control systems, and submarine repeaters.
9)	ROHM shall have no responsibility for any damages or injury arising from non-compliance with the recommended usage conditions and specifications contained herein.
10)	ROHM has used reasonable care to ensure the accuracy of the information contained in this document. However, ROHM does not warrants that such information is error-free, and ROHM shall have no responsibility for any damages arising from any inaccuracy or misprint of such information.
11)	Please use the Products in accordance with any applicable environmental laws and regulations, such as the RoHS Directive. For more details, including RoHS compatibility, please contact a ROHM sales office. ROHM shall have no responsibility for any damages or losses resulting non-compliance with any applicable laws or regulations.
12)	When providing our Products and technologies contained in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, including without limitation the US Export Administration Regulations and the Foreign Exchange and Foreign Trade Act.
13)	This document, in part or in whole, may not be reprinted or reproduced without prior consent of ROHM.



Thank you for your accessing to ROHM product informations. More detail product informations and catalogs are available, please contact us.

### ROHM Customer Support System

http://www.rohm.com/contact/