

[REF67012-EVK-001] BOM



Parts Type		Part Number	
IC	BOOST CV	BD18354MUF-M	U2
	Buck LED driver/2ch	BD18397RUV-M	U11
	Buck LED driver/3ch	BD18398RUV-M	U12
	MCU/64PIN	ML63Q805X	U5
	LIN Transceiver	BD41030FJ-C	U6
	CAN Transceiver	BD41044FJ-C	U7, U8
	DCDC Converter	BD9P608MFF-C	U4
	LDO	BD450S2EFJ-C	U1
	LDO	BD450S2WEFJ-C	U3
Transistor	Pch MOSFET/VDSS -40V ID 40A	RH7G04BBJ	Q1
	Nch MOSFET/VDSS 100V ID 59A	RD3P06BBK	Q2, Q3
Diode	Zener Diodes/VZ 10V IR0.1μA	EDZVFH10B	D1
	Bidirectional TVS/VRWM 24V IR0.1μA	RESD1CANYFH	D7, D9
	Bidirectional TVS/VRWM 24V IR0.1μA	ESD27VHYFH	D5
	TVS/VRWM 13V IR0.1μA	VS13VUA1VWMTF	D4
	Schottky diode/100V 10A	RB088RSM10	D2, D3
	Schottky diode/100V 2A	NC/RB068MM100TF	D10, D11
	Schottky diode/100V 2A	RB068MM100TF	D12, D13, D14, D15
Inductor	6.8μH@4.8A	MDH10060C-6R8NB=P3	L4
	22μH@3.5A	MDH10060C-220MB	L6,L7, L9, L10, L11
	Common mode choke/100μH(at 1MHz)	DLW43SH101XK2	U10, U9
	10μH@15.2A	SPM10065VT-100M-D	L1,L3
	4.7μH@6.7A	SPM10065VT-4R7	L2
Capacitor	4.7μF/50V	GCM31CC71H475KA03	C1, C2, C3, C6, C7, C8, C9, C10, C11, C34, C35, C36
	100nF/50V	GCM155L8EH104KE07	C4, C5, C24, C31, C37, C43, C46, C113, C114, C133, C134, C136, C142
	100nF/100V	GCM21BR72A104KA37	C13, C38, C98, C105, C106, C118, C123, C126
	4.7μF/100V	GCM32DC72A475KE02L	C14, C15, C16, C17, C39, C40, C41, C42, C101, C102, C103, C104, C121, C122, C124, C125
	0.047μF/16V	GCM155L81C473KA37	C18, C33
	4.7μF/16V	GCM21BR71C475KA67L	C21, C27, C70, C74, C82, C108, C110, C128, C130
	10μF/16V	GCM21BC71C106KE36	C22, C29
	100nF/16V	GCM155R71C104KA55	C25, C32, C54, C58, C59, C60, C62, C63, C64, C66, C67, C68, C69, C71, C72, C73, C77, C78, C80, C83, C86, C88, C90, C91
	1μF/50V	GCM188D71H105KE36	C26, C48, C107, C127
	10μF/50V	GCM31CD71H106KE36	C45
	0.022μF/50V	GCM155R71H223KA55J	C47
	22μF/16V	GCM31CC71C226ME36	C49, C50, C51, C52, C53
	1nF/16V	GCM033R71E102KA03	C55, C85
	1μF/16V	GCM188R71C105KA64	C61, C65, C75, C76, C79, C81
	4.7nF/50V	GCM155L81H472KA37	C92, C93
	2.2μF/10V	GCM188C71A225KE02	C109, C115, C129, C135, C139
	0.22μF/100V	GCM31MR72A224KA37	C111, C112, C116, C117, C131, C132, C137, C138, C140, C141
	NC	-	C28, C99, C100, C119, C120, C143
	100μF/100V	100SEV100M12.5X16	C12, C20

[REF67012-EVK-001] BOM



Parts Type		Part Number	
Resistor	10K Ω /1%	MCR01MZPF1002	R1, R2, R6, R15, R16, R18, R22, R28, R37, R38, R39, R40, R43, R44, R45, R48, R53, R57, R58, R105, R106, R107, R108, R109, R111
	0.02 Ω /1%	LTR18EZPFSR020	R3, R25
	6.8K Ω /5%	MCR01SMQPJ682	R4, R24
	47K Ω /1%	MCR01SMQPF4702	R5, R9, R68, R76, R84, R92, R97
	2.2 Ω /5%	MCR01SMQPJ2R2	R7, R19
	2.4K Ω /5%	MCR01SMQPJ243	R8, R23, R52
	0 Ω /1%	MCR01MZPJ000	R10, R26, R32, R34, R35, R41, R47, R50, R55, R56, R66, R71, R73, R81, R87, R89, R90, R110
	NC		R11, R29, R31, R33, R36, R100, R101, R102, R103, R104
	0.1K Ω /1%	MCR01SMQPF1000	R12
	30K Ω /5%	MCR01SMQPJ303	R17
	620K Ω /1%	MCR01SMQPF6203	R20
	24.9K Ω /1%	MCR01SMQPF2492	R21
	80.6K Ω /1%	MCR01SMQPF8062	R27
	20K Ω /1%	MCR01SMQPF2002	R30
	1K Ω /5%	MCR01SMQPF1001	R42, R46, R49, R51, R63, R64, R69, R72, R78, R79, R83, R85, R93, R94
	33K Ω /5%	MCR01SMQPJ333	R54
	62 Ω /1%	MCR03SEQPF62R0	R59, R60, R61, R62
	4.7 Ω /5%	MCR01SMQPJ4R7	R65, R74, R80, R88, R95
	100m Ω /1%	LTR18EZPFLR100	R67, R75, R82, R91, R96
	51K/1%	MCR01SMQPF5102	R70, R86
	4.7K Ω /5%	MCR01SMQPJ472	R77, R98
Bead	30 Ω @at 100MHz/5A	BLM18KG300TH1	BEAD1
	240 Ω @at 100MHz/350mA	BLM15AG700SH1	BEAD2, BEAD3
Crystal	8MHz	CSTNE8M00G52A000R0	Y1
Connector	2X1/Board to board connector	2182160220	J1, J2, J3, J4, J5, J6
	5X2 2.54mm/ Pin header	NC	P1
	8X2 1.27mm/ Pin header	NC	P2,P5,P8
	5X2 1.27mm/ Pin header	NC	P6

Important Notes on the Use of Reference Designs

- 1) The contents of this document are subject to change without notice for the purpose of improvement.
- 2) ROHM provides reference designs (including, but not limited to, circuit diagrams, layout data, parts lists, reference boards and their evaluation results, etc.) and all materials related to evaluation boards (hereinafter collectively referred to as "Reference Designs, etc.") to customers for the purpose of referencing them in the development of devices, equipment, software, etc. incorporating ROHM products (hereinafter collectively referred to as "Customer Products"). The design, verification, etc. required for the development of the Customer's Product shall be done at the customer's responsibility and expense. In no event shall the customer use the Reference Designs, etc. for any purpose other than the purpose mentioned above.
- 3) Reference Designs, etc. are provided on an "as is" basis. ROHM disclaims all warranties, express or implied, including, but not limited to, warranties of usefulness, functionality, accuracy, merchantability, and fitness for a particular purpose. In no event shall ROHM be liable for any damages (including, but not limited to, lost profits or other incidental, consequential, or punitive damages) arising out of, related to or in connection with the use of or application of the Reference Designs, etc. whether in contract or tort. For the avoidance of doubt, ROHM does not warrant that the Reference Designs, etc. will work with the Customer's Product.
- 4) When using Reference Designs, etc. be sure to request and verify the latest specifications (including the specifications of the products that compose the Reference Design, etc.) separately.
- 5) The customer shall be responsible for implementing safety measures such as derating, redundant design, fire prevention, backup, and fail-safe measures, etc., to prevent personal injury, fire damage, etc., caused by the Customer's Product developed with Reference Designs, etc. ROHM assumes no liability whatsoever for any use in excess of the ratings or in case of failure to observe the instructions for use.
- 6) The application circuit examples, constants, and other information provided in Reference Designs, etc. are intended to illustrate standard operation and usage. Therefore, when designing for mass production, please take into account various external conditions.
- 7) Reference Designs, etc. are intended to show typical operations and examples of application circuits, etc., and do not constitute a license, express or implied, to implement or use any intellectual property rights or any other rights of ROHM or any other company. ROHM shall not be liable for any disputes arising from, related to or in connection with the use of the Reference Designs, etc.
- 8) Please make sure to contact ROHM and obtain ROHM's consent before using the Reference Designs, etc. for the following Customer's Product that requires particularly high reliability. Transportation equipment (in-vehicle, ship, railroad, etc.), trunk line communication equipment, traffic signal equipment, disaster and security equipment, safety equipment, medical equipment, servers, solar cells, power transmission systems, etc.
- 9) Do not use Reference Designs, etc. for the following Customer's Product that requires extremely high reliability. Aerospace equipment, nuclear power control equipment, submarine relay equipment, etc.
- 10) Do not use Reference Designs, etc. for military use, such as development of weapons of mass destruction, or for any other military purpose.
- 11) ROHM does not assume any liability for any accidents or damages caused by non-compliance with the descriptions in this document.
- 12) The information contained in this document has been carefully prepared to ensure accuracy. However, ROHM shall not be liable for any loss or damage incurred by customers due to errors or misprints in this document.
- 13) Do not reproduce or duplicate any part of this document in any form or by any means without ROHM's permission.



Thank you for your accessing to ROHM product informations.
More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

<http://www.rohm.com/contact/>