

Product	Transistor	Туре	2SAR587D3
Package	TO-252 <dpak></dpak>	JEDEC Code	TO-252

1. Thermal Resistance / 熱抵抗データ



測定項目	記号	測定値	単位
ITEM	SYMBOL	VALUE	UNIT
ジャンクション - 雰囲気間熱抵抗 Thermal resistance between junction and ambient temparature	$R_{th(j-a)}$	125.0	°C/W
ジャンクション - ケース間熱抵抗 Thermal resistance between junction and case	$R_{th(j-c)}$	30.0	°C/W

R_{th(j-c)}は、周囲温度25ºCにおいて、ケース標印面の最高温点を放射温度計にて測定しました。

この時のケース温度をT_{case}とし、また、ジャンクション温度をTjとして、以下の式より算出しました。

We calculated Rth(j-c) using the below formula.

Case temperature(Tcase) was measured at the point of maximum temperature of the top side of the case(the marking side)under the condition of


Ta=25℃ by radiation thermometer.

$$R_{th(j-c)} = \frac{T_j - T_{case}}{Pc}$$
 Pc:印加電力

Applied Power

R_{th(j-a)},R_{th(j-c)}は、実装基板や半田付けによる放熱条件やケース温度測定方法によって 大きく(~数倍程度)変化しますので、あくまでも参考データとしてご活用ください。 Generally speaking, the values of R_{th(j-a)} and R_{th(j-c)} may vary depending on the thermal radiation ability of the board on which the device is mounted, as well as the device itself. Therefore, the value of R_{th(j-a)} and R_{th(j-c)} measured under our board condition can be very different from the one measured under customer's board condition. In other words, the value of R_{th(j-a)} and R_{th(j-c)} measured under our condition cannot always be applied to customer's condition.

2. Transient Thermal Resistance / 過渡熱抵抗



	Notes
1)	The information contained herein is subject to change without notice.
2)	Before you use our Products, please contact our sales representative and verify the latest specifica- tions.
3)	Although ROHM is continuously working to improve product reliability and quality, semicon- ductors can break down and malfunction due to various factors. Therefore, in order to prevent personal injury or fire arising from failure, please take safety measures such as complying with the derating characteristics, implementing redundant and fire prevention designs, and utilizing backups and fail-safe procedures. ROHM shall have no responsibility for any damages arising out of the use of our Poducts beyond the rating specified by ROHM.
4)	Examples of application circuits, circuit constants and any other information contained herein are provided only to illustrate the standard usage and operations of the Products. The periphera conditions must be taken into account when designing circuits for mass production.
5)	The technical information specified herein is intended only to show the typical functions of and examples of application circuits for the Products. ROHM does not grant you, explicitly or implicitly any license to use or exercise intellectual property or other rights held by ROHM or any other parties. ROHM shall have no responsibility whatsoever for any dispute arising out of the use of such technical information.
6)	The Products are intended for use in general electronic equipment (i.e. AV/OA devices, communi- cation, consumer systems, gaming/entertainment sets) as well as the applications indicated in this document.
7)	The Products specified in this document are not designed to be radiation tolerant.
8)	For use of our Products in applications requiring a high degree of reliability (as exemplified below), please contact and consult with a ROHM representative : transportation equipment (i.e cars, ships, trains), primary communication equipment, traffic lights, fire/crime prevention, safety equipment, medical systems, servers, solar cells, and power transmission systems.
9)	Do not use our Products in applications requiring extremely high reliability, such as aerospace equipment, nuclear power control systems, and submarine repeaters.
10)	ROHM shall have no responsibility for any damages or injury arising from non-compliance with the recommended usage conditions and specifications contained herein.
11)	ROHM has used reasonable care to ensure the accuracy of the information contained in this document. However, ROHM does not warrants that such information is error-free, and ROHM shall have no responsibility for any damages arising from any inaccuracy or misprint of such information.
12)	Please use the Products in accordance with any applicable environmental laws and regulations such as the RoHS Directive. For more details, including RoHS compatibility, please contact a ROHM sales office. ROHM shall have no responsibility for any damages or losses resulting non-compliance with any applicable laws or regulations.
13)	When providing our Products and technologies contained in this document to other countries you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, including without limitation the US Export Administration Regulations and the Foreign Exchange and Foreign Trade Act.
14)	This document, in part or in whole, may not be reprinted or reproduced without prior consent o ROHM.



Thank you for your accessing to ROHM product informations. More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

http://www.rohm.com/contact/

General Precaution

- 1. Before you use our Products, you are requested to carefully read this document and fully understand its contents. ROHM shall not be in any way responsible or liable for failure, malfunction or accident arising from the use of any ROHM's Products against warning, caution or note contained in this document.
- 2. All information contained in this document is current as of the issuing date and subject to change without any prior notice. Before purchasing or using ROHM's Products, please confirm the latest information with a ROHM sales representative.
- 3. The information contained in this document is provided on an "as is" basis and ROHM does not warrant that all information contained in this document is accurate and/or error-free. ROHM shall not be in any way responsible or liable for any damages, expenses or losses incurred by you or third parties resulting from inaccuracy or errors of or concerning such information.