ROHM Solution Simulator

Automotive Ground Sense Operational Amplifiers

BA2904/2Yxx-C – Voltage Follower (Sine Wave Input) – Transient Response simulation

This circuit simulates the transient response to sine wave input with voltage follower configured Op-Amps. You can observe the output voltage and how faithfully the sine wave input voltage is reproduced. You can customize the parameters of the components shown in blue, such as VSOURCE, or peripheral components, and simulate the voltage follower with the desired operating condition.

You can simulate the circuit in the published application note: Operational amplifier, Comparator (Tutorial). [JP] [EN] [CN] [KR]


General Cautions

Caution 1: The values from the simulation results are not guaranteed. Please use these results as a guide for your design. *Caution 2:* These model characteristics are specifically at Ta=25°C. Thus, the simulation result with temperature variances may significantly differ from the result with the one done at actual application board (actual measurement).

Caution 3: Please refer to the Application note of Op-Amps for details of the technical information. Caution 4: The characteristics may change depending on the actual board design and ROHM strongly recommend to

double check those characteristics with actual board where the chips will be mounted on.


1 Simulation Schematic



2 How to simulate

The simulation settings, such as parameter sweep or convergence options, are configurable from the 'Simulation Settings' shown in Figure 2, and Table 1 shows the default setup of the simulation.

In case of simulation convergence issue, you can change advanced options to solve. The temperature is set to 27 °C in the default statement in 'Manual Options'. You can modify it.



	Settings deladit Setup	
Parameters	Default	Note
Simulation Type	Time-Domain	Do not change Simulation Type
End Time	300 µs	-
	Balanced	-
Advanced options	Time Resolution Enhancement Convergence Assist	-
Manual Options	.temp 27	-

Table 1	Simulation	settings	default	setup
	Onnulation	Soungs	uciaun	Joiup

3 Simulation Conditions

Table 2. List of the simulation condition parameters

Instance	Turna	Parameters	Default Variable Range		Range	Units	
Name	Туре	Farameters	Value	Min	Max	Units	
		Frequency	10k	10	1M	Hz	
		Peak_voltage	0.5	0	36	V	
		Initial_phase	0 free		0		
VSOURCE \	Voltage Source	DC_offset	2.5	0	36	V	
		DF	0.0	fixed		1/s	
		AC_magnitude	0.0	fixed		V	
		AC_phase	0.0	fixed		0	
		Voltage_level	5	3 ^(Note1)	36 ^(Note1)	V	
VCC	Voltage Source For Op-Amp	AC_magnitude	0.0	fixed		V	
	For Op-Amp	AC_phase	0.0	fixed		0	

(Note 1) Set it to the guaranteed operating range of the Op-Amps.

3.1 VSOURCE parameter setup

Figure 3 shows how the VSOURCE parameters correspond to the VIN stimulus waveform.




Figure 3. VSOURCE parameters and its waveform

4 Op-Amp model

Table 3 shows the model pin function implemented. Note that the Op-Amp model is the behavioral model for its input/output characteristics, and neither protection circuits nor functions unrelated to the purpose are implemented.

Pin Name	Description				
+IN	Non-inverting input				
-IN Inverting input					
VCC	Positive power supply				
VEE	Negative power supply / Ground				
OUT	Output				

|--|

5 Peripheral Components

5.1 Bill of Material

Table 4 shows the list of components used in the simulation schematic. Each of the capacitors has the parameters of equivalent circuit shown below. The default values of equivalent components are set to zero except for the ESR of C. You can modify the values of each component.

Turne	Instance Name	Default Value	Variable	e Range	Units	
Туре	Instance Marne	Delault value	Min	Max	Units	
Resistor	R1_1	0	0	10	kΩ	
Resistor	RL1	10k	1k	1M, NC	Ω	
Consoitor	C1_1	0.1	0.1	22	pF	
Capacitor	CL1	100	free	, NC	pF	

Table 4. List of capacitors used in the simulation circuit

5.2 Capacitor Equivalent Circuits

operty Editor	-14	×				
apacitor_model_v2						
Label CL1		•				
CVALUE 100p	F	Sweep				
ESR	6	Sweep				
2m	Ohm	\odot				
ESL		Sweep				
0	Н	Ø	P1			
USE_INITIAL_VO	LTAGE	N		CVALUE	ESR	ESL
INITIAL_VOLTAGE		Sweep				
0.0	V	SS.				

(a) Property editor

(b) Equivalent circuit

Figure 4. Capacitor property editor and equivalent circuit

The default value of ESR is $2m \Omega$.

(Note 2) These parameters can take any positive value or zero in simulation but it does not guarantee the operation of the IC in any condition. Refer to the datasheet to determine adequate value of parameters.

6 Recommended Products

6.1 Op-Amp

BA2904YF-C : Standard Ground Sense Operational Amplifier. [JP] [EN] [CN] [KR] [TW] [DE] BA2904YFV-C : Standard Ground Sense Operational Amplifier. [JP] [EN] [CN] [KR] [TW] [DE] BA2904YFVM-C : Standard Ground Sense Operational Amplifier. [JP] [EN] [CN] [KR] [TW] [DE] BA2902YF-C : Standard Ground Sense Operational Amplifier. [JP] [EN] [CN] [KR] [TW] [DE] BA2902YFV-C : Standard Ground Sense Operational Amplifier. [JP] [EN] [CN] [KR] [TW] [DE]

Technical Articles and Tools can be found in the Design Resources on the product web page.

	Notes
1)	The information contained herein is subject to change without notice.
2)	Before you use our Products, please contact our sales representative and verify the latest specifica- tions :
3)	Although ROHM is continuously working to improve product reliability and quality, semicon- ductors can break down and malfunction due to various factors. Therefore, in order to prevent personal injury or fire arising from failure, please take safety measures such as complying with the derating characteristics, implementing redundant and fire prevention designs, and utilizing backups and fail-safe procedures. ROHM shall have no responsibility for any damages arising out of the use of our Poducts beyond the rating specified by ROHM.
4)	Examples of application circuits, circuit constants and any other information contained herein are provided only to illustrate the standard usage and operations of the Products. The peripheral conditions must be taken into account when designing circuits for mass production.
5)	The technical information specified herein is intended only to show the typical functions of and examples of application circuits for the Products. ROHM does not grant you, explicitly or implicitly, any license to use or exercise intellectual property or other rights held by ROHM or any other parties. ROHM shall have no responsibility whatsoever for any dispute arising out of the use of such technical information.
6)	The Products specified in this document are not designed to be radiation tolerant.
7)	For use of our Products in applications requiring a high degree of reliability (as exemplified below), please contact and consult with a ROHM representative : transportation equipment (i.e. cars, ships, trains), primary communication equipment, traffic lights, fire/crime prevention, safety equipment, medical systems, servers, solar cells, and power transmission systems.
8)	Do not use our Products in applications requiring extremely high reliability, such as aerospace equipment, nuclear power control systems, and submarine repeaters.
9)	ROHM shall have no responsibility for any damages or injury arising from non-compliance with the recommended usage conditions and specifications contained herein.
10)	ROHM has used reasonable care to ensure the accuracy of the information contained in this document. However, ROHM does not warrants that such information is error-free, and ROHM shall have no responsibility for any damages arising from any inaccuracy or misprint of such information.
11)	Please use the Products in accordance with any applicable environmental laws and regulations, such as the RoHS Directive. For more details, including RoHS compatibility, please contact a ROHM sales office. ROHM shall have no responsibility for any damages or losses resulting non-compliance with any applicable laws or regulations.
12)	When providing our Products and technologies contained in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, including without limitation the US Export Administration Regulations and the Foreign Exchange and Foreign Trade Act.
13)	This document, in part or in whole, may not be reprinted or reproduced without prior consent of ROHM.



Thank you for your accessing to ROHM product informations. More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

http://www.rohm.com/contact/