(C-014-D) DC-DC LLC Full-Bridge Converter (Discrete)

2026 March
68UG117E Rev.001

Simulation Parameters (Dialog)

	Name	Content	unit	Default Value	Variable Range
	Transformer	Np: Primary-turns Ns: Secondary-turns Lm: Magnetizing Inductance	turns turns H	18 1 60u	1 ～ 1000 1 ～ 1000 1n～1
	Rp	Transformer Resistance	Ω	5m	1m ～ 1
	Rs	Transformer Resistance	Ω	1m	1m ～ 1
	Lr	Resonant Inductance	H	12u	1n ～ 1
	Cr	Resonant Capacitance	F	100n	1n ～ 1
	Cout	Output Capacitance Initial Voltage	F V	4.7m 50	1n ～ 1 0 ～ 80
	ESR	ESR of Cout	Ω	15m	1m ～ 1
Primary	Thcap_Primary	Thermal Capacitance	J/K	0.1	1m ～ 100
Primary	Rth_Primary	Thermal Resistance	K/W	0.1	1m ～ 100
Primary	TGND_Primary	Ambient Temperature	℃	25	-40 ～ 175
Secondary	Thcap_Secondary	Thermal Capacitance	J/K	0.1	1m ～ 100
Secondary	Rth_Secondary	Thermal Resistance	K/W	0.1	1m ～ 100
Secondary	TGND_Secondary	Ambient Temperature	℃	25	-40 ～ 175

Simulation Parameters (Table)

	Name	Content	unit	Default Value	Variable Range
	Test_time	Test time in simulation	s	0.2	10u ～ 0.5
	Vin_dc	Input Voltage	V	800	400 ～ 1,200
	Vout_dc	Output Voltage	V	50	1 ～ 1200
	Pout	Output Power	W	10k	100～30k
	fs_ref	Target Carrier Frequency	Hz	100k	10k～500k
Primary	Rg_on 1*	Gate Resistance (Source)	Ω	4.7	0.1 ～ 100
Primary	Rg_off 1*	Gate Resistance (Sink)	Ω	2.0	0.1 ～ 100
Primary	DT1	Dead Time	s	100n	0 ～1m
Secondary	Rg_on 2*	Gate Resistance (Source)	Ω	10	0.1 ～ 100
Secondary	Rg_off 2*	Gate Resistance (Sink)	Ω	10	0.1 ～ 100
Secondary	DT2	Dead Time	s	100n	0 ～1m
	T_init**	Initial Junction Temp.	℃	25	-40 ～ 175

*Common for all MOSFETs in the same side. **Common for all devices

Simulation Circuit



Default Devices

Name	Device Type	Part No.	Specification
Q1~4	SiC MOSFET	SCT4018KR	1200V/ 81A/ 18mΩ/ TO-247-4L
Q5～12	Si MOSFET	RS7N200BH	80V/ 200A/ 1.7mΩ/ DFN5060-8S

Simulation Screen Overview

2026 March
68UG117E Rev.001

Schematic window
- Dialog parameters setting
- Results display

Device selection

Table parameters setting

Simulation control

Trace selection





Waveforms

Simulation Results 1

2026 March
68UG117E Rev.001

Input and Output





Contents	Results
Input Power : Pin	10.140 (kW)
Output Power: Pout	9.915 (kW)
Efficiency: η	97.79 (%)

Simulation Results 2

2026 March
68UG117E Rev.001

Primary side





Contents	Results
Conduction Loss: Pcond (primary)	6.33 (W/device)
Switching Loss: Psw (primary)	5.78 (W/device)
Junction Temp. : Tj (primary)	34.39 (℃)
Heatsink Temp.: T_hs (primary)	29.88 (℃)
Total Loss: Ptot (primary)	48.44 (W)

Simulation Results 3

2026 March
68UG117E Rev.001

Secondary side





Contents	Results
Conduction Loss: Pcond (secondary)	14.70 (W/device)
Junction Temp. : Tj (secondary)	47.19 (℃)
Heatsink Temp.: T_hs (secondary)	36.92 (℃)
Total Loss: Ptot (secondary)	117.64 (W)

How to change the devices

The figure of “(A-011-D) DC-AC Totem-Pole PFC Diode Rectification (Discrete)” is used as an example in this page.

2026 March
68UG117E Rev.001

Device Selection



Over your mouse cursor to the device name that you want to change and click the left button of the mouse.



Available device lists are appeared like the above, and you can select a favorite device from these.

How to change Dialog parameters

The figure of “(A-011-D) DC-AC Totem-Pole PFC Diode Rectification (Discrete)” is used as an example in this page.

2026 March
68UG117E Rev.001

- Symbols whose parameters can be changed are colored light-blue in the circuit diagram.
- Over your mouse cursor to the symbol that you want to change the parameter and the symbol color is turned to blue (e.g. “V_ac” symbol in the below).
- Click the mouse’s left button.



- A new window like the below is opened.
- You can change the parameters by entering the value directly* or selecting radio buttons.
- Push “Apply” button after changing all parameters.



*Note: Parameters can be entered directly are limited by Min. and Max. values to avoid unexpected system errors.
(e.g. “Vin(peak)” is limited between 100 and 500V in the above.)

How to change Table parameters

The figure of “(A-011-D) DC-AC Totem-Pole PFC Diode Rectification (Discrete)” is used as an example in this page.

2026 March
68UG117E Rev.001

Table parameters





Choose the parameter that you want change on the parameter tables (e.g. ”60kHz” of Switching Frequency in the left figure.)

- A blue under-line and variable range of the parameter are appeared.
- Then, you can change the parameters by entering the value directly ” (e.g. “60kHz” was changed to “20kHz”).

Notice

1) The information contained in this document is intended to introduce ROHM Group (hereafter referred to asROHM) products. When using ROHM products, please verify the latest specifications or datasheets before use.

2) ROHM products are designed and manufactured for use in general electronic equipment and applications (such as Audio Visual equipment, Office Automation equipment, telecommunication equipment, home appliances, amusement devices, etc.) or specified in the datasheets. Therefore, please contact the ROHM sales representative before using ROHM products in equipment or devices requiring extremely high reliability and whose failure or malfunction may cause danger or injury to human life or body or other serious damage (such as medical equipment, transportation, traffic, aircraft, spacecraft, nuclear power controllers, fuel control, automotive equipment including car accessories, etc. hereafter referred to as Specific Applications). Unless otherwise agreed in writing by ROHM in advance, ROHM shall not be in any way responsible or liable for any damages, expenses, or losses incurred by you or third parties arising from the use of ROHM Products for Specific Applications.

3) Electronic components, including semiconductors, can fail or malfunction at a certain rate. Please be sure to implement, at your own responsibilities, adequate safety measures including but not limited to fail-safe design against physical injury, and damage to any property, which a failure or malfunction of products may cause.

4) The information contained in this document, including application circuit examples and their constants, is intended to explain the standard operation and usage of ROHM products, and is not intended to guarantee, either explicitly or implicitly, the operation of the product in the actual equipment it will be used. As a result, you are solely responsible for it, and you must exercise your own independent verification and judgment in the use of such information contained in this document. ROHM shall not be in any way responsible or liable for any damages, expenses, or losses incurred by you or third parties arising from the use of such information.

5) When exporting ROHM products or technologies described in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, such as the Foreign Exchange and Foreign Trade Act and the US Export Administration Regulations, and follow the necessary procedures in accordance with these provisions.

6) The technical information and data described in this document, including typical application circuits, are examples only and are not intended to guarantee to be free from infringement of third parties intellectual property or other rights. ROHM does not grant any license, express or implied, to implement, use, or exploit any intellectual property or other rights owned or controlled by ROHM or any third parties with respect to the information contained herein.

7) No part of this document may be reprinted or reproduced in any form by any means without the prior written consent of ROHM.

8) All information contained in this document is current as of the date of publication and subject to change without notice. Before purchasing or using ROHM products, please confirm the latest information with the ROHM sales representative.

9) ROHM does not warrant that the information contained herein is error-free. ROHM shall not be in any way responsible or liable for any damages, expenses, or losses incurred by you or third parties resulting from errors contained in this document.

ROHM SEMICONDUCTOR

Thank you for your accessing to ROHM product informations.
More detail product informations and catalogs are available, please contact us.

ROHM Customer Support System

https://www.rohm.com/contactus